


**1. Remove the goals from the bag****2. Unfold and lay flat with the Avanti logo facing up and strap A unfastened.****3. Fasten the ends of the strap (A to B).****4. Lock the corner hinges****5. Anchor and ready to play!**